

**Smart Watch:  
GM8588**

**User Guide**


**Please read the manual before  
use.**

## 1. Safety Warning

- ◆ The information in this document won't be modified or extended in accordance with any notice.
- ◆ The watch should be charged for 2 hours at minimum before entering security code.
- ◆ The original code is 1122. This code will prevent your watch to be accessed by others without your permission.
- ◆ Please change the original code to ensure your personal information is safe.

## 2. Product details:

### 2.1 Product details




Power button: Power On/Off

### 2.2 Products quick into

You can enter into next page by sliding screen to the left, and return to last page by sliding screen right; enter into the notice board after sliding from up to down, and return to main mean from down to up. It is will be in mistake for a click if the drag distance too short.

## 2.3 Clock Display (the following picture is for reference only, please in kind prevail)



### Setting method:


Method 1: Power on , when the phone in clock mode, please click middle screen and set different clock interfaces if you like.

Method 2: Power on, Main menu: setting—phone setting—standby menu display—unlock selection, choose the clock mode if you like.

## 2.4 Product theme settings (the following picture is for reference only, please in kind prevail)



glaring



dream



classic



harmonious



colorful

**Setting method:**

**3. Product quick use**

**3.1 Download the Sync software.**

[www.styleasia.net/downloads/smartwatch.apk](http://www.styleasia.net/downloads/smartwatch.apk)

**Or**

Scan the following QR code, which will direct you to download the required Application. This App will be used to sync your phone with watch.



**Install and use the Sync software**

Android Application installation:

Once downloading is complete, Please install the android application in your smart phone. To install application enter settings and allow installation from unknown sources.

Once the application is installed, connect your smartphone to your smartwatch via Bluetooth.

(Smart phone) Setting—Bluetooth—Enable Bluetooth settings in “discoverable mode” (Please choose “sure” when shown a warning notices) the application runs on the background automatically and sync function will be switched on as below:



Click the Bluetooth notices and choose the Notification service, select your Personal or System application in Notify application.

Telephone service is including SMS, incoming call and seek watch.

Notice:

Please don't shut the Bluetooth notify service when you are clearing software by background or close background application software. It will affect the Sync function between watch and phone if shut it.

### **3.2 Bluetooth Connection and Sync function**

#### **3.2.1 From phone to watch**

Phone setting—turn on the Bluetooth—search for

devices, please click pair devices when found W90. and also choose “yes” in your mobile phone, paired done.

Please choose “sure” when there is phone book request. Meanwhile you’d better choose “no remind again”, this is convenience when you connect next time (without remind again).

Notice: the Sync software can open in sync APP already installed and Accessibility, the mobile will show Bluetooth connected done after 2-5 min; the watch will inform you the time of Sync with phone, than the Sync switched on. The message will sync to you watch when it incoming to mobile.

### **3.2.2 From watch to phone**

BT dialer on Smart watch --Search new device—found your smart watch (such as s9500)—connect The processes of next are same with

3.3.1

## **3.4 Base function**

### **3.4.1 Message**

Sync phone or watch message.

### **3.4.2 Bluetooth**

Sets the Bluetooth status, turn on/off.

### **3.4.3 Calls records**

You can check your phone call records after you connect with the Bluetooth.

Shown all records including miss call, dialed calls and receive call; You can check the date, time and phone number of the miss call after you choose it. But only can call this number.

#### **3.4.4 BT dialer**

Paired devices from smart watch

#### **3.4.5 remote notifier (Only for Android users)**

When there is SMS, incoming messages from QQ and other applications on the connected phone, the watch phone will alert you to read them.

#### **3.4.6 Remote cameras**

Use phone camera take photos, but remote by watch, its need switch on the camera of phone in advance.

#### **3.4.7 Anti lost**

Watch seek phone, or phone seek watch.

#### **3.4.8 Setting**

Notice: sets clocks display and theme in phone setting. In the security Settings. The safe code is 1122.

#### **3.4.9 Padometer**

It can be adopted as a tool to avoid insufficient or excessive exercise by measuring calorier or calories consumption based on collected data, such as number of steps, distance, speed time, etc. to control exercise. If you want return to main menu but keep pedometer during the exercise. Please press the power button.

#### **3.4.10 Sleep monitor**

Show your sleep quality base on your sleep times.

#### **3.4.11 Sedentary remind**

You can set a time to remind you up to do some exercise, we suggest you this time could be one hours.

#### **3.4.12 Quick response**

It can download sync software when scan the quick response, if there is a new version need to update, please contact with our servicer, our company will

provide a new link for your download.

### **3.4.13 Smart watch**

Search information about watch

### **3.4.14 Alarm**

### **3.4.15 Calendar**

### **3.4.16 Calculator**

### **3.4.17 Profiles**

### **3.4.18 File manager**

### **3.4.19 Audio player**

Can play music from local or smart phone after connect with Bluetooth.

### **3.4.20 Theme Setting**

### **3.4.21 Camera**

### **3.4.22 Video recorder**

### **3.4.23 Image viewer**

### **3.4.24 Video player**

### **3.4.25 Sounder recorder**

### **3.4.26 Phone QQ**

QQ need your phone has SIM card and can surf the Internet

### **3.4.27 Browser**

Browser need your phone has SIM card and can surf the Internet.

### **4.4.28 SIM tool**

## **4. Notice**

Main menu: Theme setting, choose the theme if you like.

**4.1** Full charge before use, the charge time need 1-2 hours.

**4.2** Use the accessories cable and charger, or your android phone accessories.

**4.3** Bluetooth will disconnect when exceed the distances, after switch on the Anti lost. The smart search function can't be use before reconnect with Bluetooth.

**4.4** Please reconnect with BT if it's disconnected occasionally (please Manual connect if the Bluetooth disconnect over 5 minutes). Please agree the phone book Sync otherwise there is no called phone book.

**4.5** When playing the music, some of music's name can shown and some can't, it is normal. Because android phone are difference.

## **5. Common trouble shooting**

Please refer below key function for any problems with the watch, if the problem is still unsolved, please contact with your dealer or serviceman appointed.

**5.1** Unable to switch on

The time of press the power button too short, please keep it more than 3 seconds

Low power, please charge it.

**5.2** Shut down automatically

Low power, please charge it.

**5.3** Using time too short.

Battery is not full, please make sure it is full power (full charge need 2hours at least).

During the use of SIM card, the power will be run off soon if the signal too poor.

**5.4** Unable to charge.

The battery's life will be reduce after few years, please check if the battery are work.

Change a new charger if it is unworkable.

Please check the USB slot connecting good, if no, please try again.

**5.5** No caller's name when incoming call

Forgot to choose upload the phone book when connected with BT, or unselected keep upload the phone book.

Forgot to sync the phone book when reconnected, please pair the device and connect BT again.

**5.6** Bad phone call voice

Watch and phone are separated too far, please be more close; Bad signal of BT.

Bad signal of your own phone call place, please change a more better place for phone call.